Amana Smart Thermostat Commissioning Menu Outline for Unitary Equipment, v3.9 software

Level 1	Level 2	Level 3	Level 4	Level 5	Level 6	Default	Display only?	Conditions
welcome	**english** **español** **française**	(radio buttons)				english		
	use large font	(checkbox)				unchecked		
	continue							
setup	**begin setup**	(to smart thermostat setup with 5 main steps below)						
	setup options	factory reset						
	learn more	firmware (version #)					Yes	
		check for update						
	thermostat ID (DKN number)	(2D barcode of DKN number for cloud commissioning)					Yes	
		dismiss					Yes	
1. Communication	**equipment type**	unitary				unitary		
	wifi	use wifi						
		networks	(list of available networks) search again					Only appears when "use wifi" selected
		internet connected (tickmark)					Yes	Only appears when connected to acive wifi network.
		Daikin One Cloud connected (tickmark)					Yes	Only appears if successfully connect to internet.
		legal notices	terms of use	(text)			Yes	
			privacy policy	(text)			Yes	
			end user license agreement	(text)			Yes	
		restart thermostat					Yes	If internet connected but not cloud
2. Personalization	**language**	english español française				english		
	use large font	(checkbox)				unchecked		
	date & time	(month, day, and year selection)						set automatically when connect to WiFi.
		(hour, minute, and am/pm selection)						set automatically when connect to WiFi.
		use 24-hour time format				disabled		
		time zone	(list of time zones)			Pacific		set automatically when connect to mobile app.
	name	main room upstairs downstairs hallway bedroom kitchen other (other name)	(text entry for other)			main room		
	degree units	fahrenheit celsius				fahrenheit		
	Air Conditioner (model # from CT)	Specifications	Model #				Yes	If scan successful
			Serial #				Yes	
			Control Software Version				Yes	
			Inverter Software Version				Yes	Inverter only
			Number of cool stages				Yes	
			Number of heat stages				Yes	Will display for AC, as "0" stages.
			Tonnage				Yes	
		Cool Settings	Cool Airflow Trim	Low speed trim	-15% to 15% in 3% steps			Inverter AC only, but not with DTA furnace adaptors
					-15%, -10, -5, 0, 5, 10, 15, 20, 30, Max			Amana S Series only, but not with DTA furnace adaptors
				Intermediate speed trim	'-15% to 15% in 3% steps			Inverter AC only, but not with DTA furnace adaptors
					-15%, -10, -5, 0, 5, 10, 15, 20, 30, Max			Amana S Series only, but not with DTA furnace adaptors
				High speed trim	'-15% to 15% in 3% steps			Inverter AC only, but not with DTA furnace adaptors
					-15%, -10, -5, 0, 5, 10, 15			Amana S Series only, but not with DTA furnace adaptors
				-10% to 10% in 2% steps				2-stage models only
			Cool Profile	Profile A Profile B Profile C Profile D				Not available with DTA furnace adaptors
			Cool Airflow ON Delay	0, 5, 10, 20, 30s				0s option added to Amana S in 2025.
			Cool Airflow OFF Delay	0, 30, 60, 90, 120s				0s option added to Amana S in 2025.
			Max compressor RPS				Yes	Inverter only
			RPS offset	0 to 20 in 0.5 RPS steps				Inverter only; can't be changed for All-climate HP and 5-ton enhanced Amana S.
			Dehumidification	Off, On				
				Off, Standard, A (widest range), B (reduced range), C (100% operation only)				Amana S Series only
			Circulation selection	Off, On				Amana S Series only
		Specifications	Model #				Yes	
			Serial #				Yes	
			Control Software Version				Yes	
			Inverter Software Version				Yes	Inverter only
			Number of cool stages				Yes	
			Number of heat stages				Yes	
			Tonnage				Yes	
		Cool Settings	Cool Airflow Trim	Low speed trim	'-15% to 15% in 3% steps			Inverter HP only, but not with DTA furnace adaptors
					-15%, -10, -5, 0, 5, 10, 15, 20, 30, Max			Amana S Series only, but not with DTA furnace adaptors
				Intermediate speed trim	'-15% to 15% in 3% steps			Inverter HP only, but not with DTA furnace adaptors
					-15%, -10, -5, 0, 5, 10, 15, 20, 30, Max			Amana S Series only, but not with DTA furnace adaptors
				High speed trim	'-15% to 15% in 3% steps			Inverter HP only, but not with DTA furnace adaptors
					-15%, -10, -5, 0, 5, 10, 15			Amana S Series only, but not with DTA furnace adaptors
				-10% to 10% in 2% steps				2-stage models only
			Cool Profiles	Profile A Profile B Profile C Profile D				
			Cool Airflow ON Delay	0, 5, 10, 20, 30s				0s option added to Amana S in 2025.
			Cool Airflow OFF Delay	0, 30, 60, 90, 120s				0s option added to Amana S in 2025.
			Max compressor RPS				Yes	Inverter only
			Max RPS offset	0 to 20 in 0.5 RPS steps				Inverter only; can't be changed for All-climate HP and 5-ton enhanced Amana S.
				Off, On				

3. Equipment Setup	**Heat Pump (model # from CT)**		Dehumidification	Off, Standard, A (widest range), B (reduced range), C (100% operation only)				Amana S Series only
			Circulation selection	Off, On				Amana S Series only
		Heat Settings	Heat Airflow Trim	Low speed trim	'-15% to 15% in 3% steps			Inverter HP only, but not with DTA furnace adaptors
					-15%, -10, -5, 0, 5, 10, 15			Amana S Series only, but not with DTA furnace adaptors
				Intermediate speed trim	'-15% to 15% in 3% steps			Inverter HP only, but not with DTA furnace adaptors
					-15%, -10, -5, 0, 5, 10, 15			Amana S Series only, but not with DTA furnace adaptors
				High speed trim	'-15% to 15% in 3% steps			Inverter HP only, but not with DTA furnace adaptors
					-15%, -10, -5, 0, 5, 10, 15			Amana S Series only, but not with DTA furnace adaptors
				-10% to 10% in 2% steps				2-stage models only
			Heat Airflow ON Delay	0, 5, 10, 15s				0s option added to Amana S in 2025.
			Heat Airflow OFF Delay	0, 30, 50, 70, 90s				0s option added to Amana S in 2025.
			Backup Defrost Heat	always on; always off; below temperature: 30°F, 35°F, 40°F, 45°F, 50°F, 55°F, 60°F, 65°F;				Amana S Series only
			Defrost Interval	30, 60, 90, 120 min;				HP only
				2 hr, 6 hr, 12 hr, 24hr;				R32 HP only, from mid-2025
			Defrost Compressor Delay	0, 5, 15, 30s				2-stage R410A HP only
			Max compressor RPS				Yes	Inverter only
			Max RPS offset	0 to 20 in 0.5 RPS steps				Inverter only; can't be changed for All-climate HP and 5-ton Amana S.
		Heat Pump Settings	heat pump lockout temp	-40°F to 65°F in 5°F steps (-40°C to 17.5°C in 2.5°C steps)		-5°F (-20°C)		Only displayed for systems with HP and heater kit. Is common lockout with aux heat source.
			supplemental heat lockout	-10°F to 75°F in 5°F steps (-22.5°C to 22.5°C in 2.5°C steps)		50°F (10°C)		Only displayed for systems with HP and heater kit. Doesn't apply to an aux heat source.
			balance point	-10°F to 75°F in 5°F steps (-22.5°C to 22.5°C in 2.5°C steps)		50°F (10°C)		Only displayed for dual-fuel systems (HP and gas furnace).
			prioritize efficiency (or) prioritize comfort	(radio buttons)		prioritize comfort		Only displayed for dual-fuel systems (HP and gas furnace).
	Furnace (model # from CT)	Specifications	Model #				Yes	
			Serial #				Yes	
			Control Software Version				Yes	
			number of heat stages				Yes	
			Size/Capacity				Yes	Not DTA furnace adaptors
			Blower Motor Size				Yes	Not DTA furnace adaptors
		Heat Settings	Gas Heat Airflow Trim	-16% to 16% in 2% steps				R32 compatible furnaces
				-15% to 15% in 3% steps				Modulating R410A furnaces only
				-10% to 10% in 2% steps				2-stage R410A furnaces only, not DTA furnace adaptors
			Gas Heat Airflow ON Delay	5 to 30s in 5s steps				Modulating and 2-stage R410A furnaces, not DTA furnace adaptors
			Gas Heat Airflow OFF Delay	30 to 180s in 30s steps				Modulating and 2-stage R410A furnaces, not DTA furnace adaptors
			Heat CFM Taps	Tap A Tap B Tap C Tap D				All R32-compatible 2-stage and ULN furnaces. At launch of R32 furnaces, must be modified on PCB or using CoolCloud app. (not supported on mod or DTA furnace adaptors)
		Humidifier Relay	Mode	Off On with heat and hum On with hum		Off		All Amana R32 furnaces (not DTA furnace adaptors). "On with hum" option not supported.
		Aux Alarm	On/Off					2-stage and ULN R410A furnaces, and all R32 furnaces
	Air Handler or Blower (model # from CT)	Specifications	Model #				Yes	
			Serial #				Yes	
			Control Software Version				Yes	
			Blower Motor Size				Yes	
		Heater Kit	Is a heater kit installed?	Yes/No		No		Non-EEV air handlers that support heater kits (used to confirm installed heater kit).
			Size (kW)	(size in kW from indoor PCB)			Yes	non-EEV air handlers
				0, 3, 5, 6, 8, 10kW				AHVE24 models that support heater kits
				0, 5, 6, 8, 10, 15, 19kW				AHVE35, AHVE36, and AHVE42 models that support heater kits
				0, 5, 6, 8, 10, 15, 20kW				AHVE47 and AHVE48 models that support heater kits
				0, 5, 6, 8, 10, 15, 20, 25kW				AHVE59 and AHVE60 models that support heater kits
				0, 3, 5, 15kW				MBVK16CH1X
				0, 5, 15, 20, 25kW				MBVK20CH1X
				0, 3kW				AWVE30, AWVE36
			Electric Heat Airflow Trim	0% to 10% in 2% steps				EEV air handlers only, including MBVKxxCH models
				-10% to 10% in 2% steps				non-EEV air handlers (ClimateTalk models with TXV) including MBVKxxxP (TXV) models
			Heat Airflow ON Delay				Yes	
			Heat Airflow OFF Delay				Yes	
		Hum/aux Relay	Humidifier Enable with Blower None					EEV air handlers only
			Humidification Mode	Off On Independent				EEV air handlers only, if humidifier selected in top menu
			Humidification Fan Speed	25, 50, 75, 100%				EEV air handlers only, if "humidifier" and "independent" selected above.
		Aux Alarm	On/Off					non-EEV air handlers and blowers.
	Coil	Configuration	Serial #				Yes	
			Software Version				Yes	
	Media filter	1, 2				1		
		Remove equipment	Do you want to remove this equipment?	Cancel Continue				
	Add Equipment	24V AC Condenser						At launch of R32 furnaces, settings must be modified on PCB or using CoolCloud app.
		Humidifier						Can only add 1 aux device.
		Dehumidifier						
		Aux heat source						
		UV bulb						Can only add 1 of each type.
		HEPA filter						Can only add 1 of each type.
		Electronic filter		low speed trim				Can only add 1 of each type.

	EWC Zone board						Can only add 1 of each type.
Indoor air quality sensor	Remove equipment	Do you want to remove this equipment?	Cancel Continue				
24V AC Condenser	Cool Settings	Cool CFM	18, 24, 30, 36, 42, 48, 60 kBTUs cooling				For R32 furnaces only, but must use CoolCloud app.
		Cool Airflow Trim	-15% to 15% in 3% steps				For R32 furnaces only, but must use CoolCloud app.
			-10% to 10% in 2% steps				For R32 furnaces only, but must use CoolCloud app.
		Cool Profiles	Profile A Profile B Profile C Profile D				For R32 furnaces only, but must use CoolCloud app.
		Cool Airflow ON Delay	5, 10, 20, 30s				For R32 furnaces only, but must use CoolCloud app.
			1, 5, 10, 20, 30s				For R32 furnaces only, but must use CoolCloud app.
		Cool Airflow OFF Delay	30, 60, 90, 120s				For R32 furnaces only, but must use CoolCloud app.
			0, 30, 60, 90, 120s				For R32 furnaces only, but must use CoolCloud app.
	Remove equipment	Do you want to remove this equipment?	Cancel Continue				For R32 furnaces, can only add or remove from thermostat.
Humidifier	Connection	Aux1					If humidifier added.
		Aux2					
	Control	On with heat On with heat and hum On with hum			On with heat and hum call		
	Fan speed	25% 50% 75% 100%					
	number of pads	1, 2					
	Remove equipment	Do you want to remove this equipment?	Cancel Continue				
Dehumidifier	Connection	Aux1					If dehumidifier added.
		Aux2					
	Control	On with cool On with cool and dehum On with dehum On with no cool and dehum			On with dehum		
	Fan speed	0% 25% 50% 75% 100%			100%		
	Remove equipment	Do you want to remove this equipment?	Cancel Continue				
Aux heat source	Connection	Aux1					
		Aux2					
				-40°F to 65°F in 5°F steps (-40°C to 17.5°C in 2.5°C steps)	-5°F (-20°C)		The whole "Heat Pump is primary heat source" only appears if connected to HP. The HP lockout must be at least 10°F < aux heat lockout.
			Aux heat lockout	Enable aux heat lockout (checkbox)	disabled		
				-10°F to 75°F in 5°F steps (-22.5°C to 22.5°C in 2.5°C steps)	50°F (10°C)		Appears if connected to HP.
			Use Ton/Toff	(checkbox)	disabled		If connected to HP
			T on / T off	Turn on temperature differential: -7°F to -3°F in 1°F steps (-4.0°C to -1.5 to in 0.5°C steps)	-3°F (-1.5°C)		Enabled automatically if connected to AC outdoor.
				Turn off temperature differential: -4°F to 1°F in 1°F steps (-2°C to 0.5°C in 0.5°C steps)	1°F (0.5°C)		Enabled automatically if connected to AC outdoor. Must be 3 or 4°F (2°C) above Ton.
			Indoor unit fan enabled	(checkbox)	On		
			Fan speed	low medium high	high		Only if indoor unit fan enabled.
			Fan on delay	0s, 30s, 60s, 120s, 180s, 240s, 300s	30s		Only if indoor unit fan enabled.
			Fan off delay	0s, 10s, 30s, 60s, 90s, 120s, 180s	10s		Only if indoor unit fan enabled.
				-40°F to 65°F in 5°F steps (-40°C to 17.5°C in 2.5°C steps)	15°F (-10°C)		
			Setpoint differential	-9°F, -7°F, -5°F, -4°F, or -2°F (-5°C to -1°C in 1°C steps)	-2°F (-1°C)		Hidden for AC outdoor unit
			T on / T off	Turn on temperature differential: -2 or -1°F (-1.0 or -0.5°C)	-1°F (-0.5°C)		
				Turn on temperature differential: 1°F (0.5°C)	1°F (0.5°C)	Yes	
			Indoor unit fan enable	(checkbox)	On		
			Fan speed	low medium high	high		Only if indoor unit fan enabled.
			Fan on delay	0s, 30s, 60s, 120s, 180s, 240s, 300s	30s		Only if indoor unit fan enabled.
			Fan off delay	0s, 10s, 30s, 60s, 90s, 120s, 180s	10s		Only if indoor unit fan enabled.
	Remove equipment	Do you want to remove this equipment?	Cancel Continue				
UV Bulb	1, 2				1		If UV bulbs added.
	Remove equipment	Do you want to remove this equipment?	Cancel Continue				
HEPA filter	1, 2				1		If HEPA filter added.
	Remove equipment	Do you want to remove this equipment?	Cancel Continue				
Electronic filter	1, 2				1		If Electronic filter added.
	Remove equipment	Do you want to remove this equipment?	Cancel Continue				
EWC Zone Board	Type	EWC Zone Board				Yes	If zone board added
	Zone 1 Additional Zone	(radio button)			Zone 1		
	heater kit installed	(checkbox)			No		Appears when "Additional Zone" selected to tell thermostat is heater kit.
	Remove equipment	Do you want to remove this equipment?	Cancel Continue				
System Test	Run test (explanation of test)						Only in inverter AC and HP
	Test status:	0: "System test required" 1: "Initial test successful"					
Charge Mode	Run test Stop (explanation of test)						Only R410A Inverter AC/HP.
Charge Verification Mode	Run test Stop (explanation of test)						Only R32 Inverter AC/HP.
	Test status:	1: "Outdoor Temp out of range - Please use gauges to adjust charge" 2: "System stabilizing" 3: "Outdoor fan speed not in range" 4: "Compressor speed not in range" 5: "Indoor SH not in range" 6: "In range -- SubCool = (SC in °F or °C)" 7: "SC in range, confirming continuous					Only R32 Inverter AC/HP.

4. System Optimization	**Refrigerant Leak Test**	Refrigerant leak test	Run test Stop (explanation of test)					R32 EEV air handlers only.
	Optional Tests	Cooling	Run test Stop (explanation of test)					If system capabilities include cooling. Runs until stopped or until setup steps completed.
		Fan	Run test Stop (explanation of test)					Runs until stopped or until setup steps completed.
		Heat Pump Heat	Run test Stop (explanation of test)					If system capabilities include cooling. Runs until stopped or until setup steps completed.
		Gas Heat	Run test Stop (explanation of test)					If system capabilities include cooling. Runs until stopped or until setup steps completed.
		Electric Heat	Run test Stop (explanation of test)					If system capabilities include cooling. Runs until stopped or until setup steps completed.
		Pump Down	Run test Stop (explanation of test)					All-climate HP, Enhanced 5-ton, and some older inverter models.
	Error History	(date and time of error) (code - equipment) (error description)					Yes	
		Clear error history?	Cancel/Continue	Yes/No				
	Calibration	Temperature calibration	-10°F to 10°F in 1°F steps (or) -5.5°C to 5.5°C in 0.5°C steps			0°F (or) 0°C		
		Humidity calibration	-15% to 15% in 1% steps			0%		
	Status	air conditioner (or) heat pump	operation mode				Yes	all equipment, enhanced for Amana S Series.
			current critical error				Yes	if currently active critical error
			current minor error				Yes	if currently active minor error
			requested heat demand				Yes	Only HP models.
			requested cool demand				Yes	all equipment
			requested indoor CFM				Yes	all equipment
			requested indoor fan demand				Yes	inverter always shows "0%", may only display for 2-stage where is valid.
			requested dehum demand				Yes	all equipment
			indoor superheat				Yes	R32 models only
			refrigerant type				Yes	R32 models only
			compressor runtime				Yes	inverter only
			compressor reduction mode				Yes	inverter only
			outdoor fan RPM				Yes	inverter only
			outdoor air temp				Yes	all equipment
			outdoor coil temp				Yes	Not 2-stage, All-climate HP, or 5-ton Enhanced Amana S
			liquid temperatures				Yes	inverter only
			discharge temperature				Yes	inverter only
			outdoor defrost sensor temp				Yes	inverter HP only
			suction temperature				Yes	inverter only
			suction pressure				Yes	inverter only
			high pressure sensor				Yes	All-climate HP and 5-ton enhanced models only
			retry code				Yes	Amana S Series only
			inverter current (A)				Yes	Amana S Series only
			inverter fin temp				Yes	Amana S Series only
			current compressor speed (%)				Yes	Amana S Series only
			current compressor speed (RPS)				Yes	Amana S Series only
			target compressor speed (RPS)				Yes	Amana S Series only
			request for compressor				Yes	Amana S Series only
			reversing valve				Yes	Amana S Series only
			request for OD fan				Yes	Amana S Series only
			OD fan motor current (A)				Yes	Amana S Series only
			target OD fan speed (RPM)				Yes	Amana S Series only
			Cold Climate HP (yes/no)				Yes	All-climate HP models only.
			request for fan2				Yes	All-climate HP and 5-ton enhanced models only
			fan2 motor current				Yes	All-climate HP and 5-ton enhanced models only
			target fan2 speed				Yes	All-climate HP and 5-ton enhanced models only
			current fan2 speed				Yes	All-climate HP and 5-ton enhanced models only
			OD EEV Opening (%)				Yes	Amana S Series only
			liquid EEV Opening (%)				Yes	All-climate HP and 5-ton enhanced models only
			powerful heating status				Yes	
			ID coil freeze protection				Yes	Amana S Series only
			crank case heater				Yes	Amana S Series only
			drain pan heater				Yes	Amana S Series only
			preheat				Yes	Amana S Series only
			preheat output (W)				Yes	Amana S Series only
		air handler	operation mode				Yes	
			current critical error				Yes	
			current minor error				Yes	
			current heat demand				Yes	
			requested heat demand				Yes	
			electric heat stages				Yes	R32 EEV air handlers only
			current indoor CFM				Yes	
			current indoor fan demand				Yes	
			requested indoor fan demand				Yes	
			requested hum demand				Yes	
			refrigerant type				Yes	EEV air handlers only
			refrigerant leak detected				Yes	R32 EEV air handlers only
			indoor superheat				Yes	EEV air handlers only, if cooling and data valid
			fan runtime				Yes	EEV air handlers only
			liquid temperature				Yes	EEV air handlers only
			suction temperature				Yes	EEV air handlers only
			pressure sensor				Yes	EEV air handlers only, removed for R32 units
			aux alarm status				Yes	EEV air handlers only, removed for R32 units
		furnace	operation mode				Yes	Hidden for DTA furnace adaptors
			current critical error				Yes	
			current minor error				Yes	
			current heat demand				Yes	
			requested heat demand				Yes	
			current cool demand				Yes	Hidden for DTA furnace adaptors
			requested cool demand				Yes	Hidden for DTA furnace adaptors
			current indoor CFM				Yes	Hidden for DTA furnace adaptors
			current indoor fan demand				Yes	Hidden for DTA furnace adaptors
			requested indoor fan demand				Yes	Hidden for DTA furnace adaptors
			requested hum demand				Yes	Hidden for DTA furnace adaptors
			requested dehum demand				Yes	Hidden for DTA furnace adaptors
		EEV	current critical error				Yes	
			current minor error				Yes	
			refrigerant type				Yes	R32 EEVs only
			indoor superheat				Yes	EEV air handlers only, if cooling and data valid; value is 32°F high;
			liquid temperature				Yes	
			suction temperature				Yes	
			pressure sensor				Yes	
		min/max setpoints	50°F to 90°F in 1°F increments (10°C to 32°C in 0.5°C steps)			50°F to 90°F (10°C to 32°C)		
		deadband / overcool	Temperature setpoint dead band: 2°F to 9°F in 1°F steps (0°C to 5°C in 0.5°C steps)			4°F / 2°C		If system capabilities include heating and cooling

		dehumidify / overcool	Overcooling allowed to dehumidify: 0, 1, 2, or 3°F (0, 0.5, 1, or 1.5°C)			0°F / 0°C		If system capabilities include cooling
	cool/heat	cooling boost mode	on, off					16-18 and newer 20 SEER inverter only
			outdoor activation temperature	Always ON, 70F, 75F, 80F, 85F, 90F, 95F, 100F, 105F				16-18 and newer 20 SEER inverter only, when boost mode on
		heating boost mode	on, off					Amana S Series only
		powerful heating	on, off					R32 inverter HPs only.
		disable humidification	(checkbox)			unchecked		Only affects systems with humidification
		enable tight setpoint control	(checkbox)			unchecked		R32 equipment only, with v3.7 release.
		quiet mode (planned for v3.7 release)	use quiet mode	(check box)		disabled		Side discharge units only
			nighttime (event 1 name)	time	(time selection in 15 min increments)	10pm		Side discharge units only
				label	(text entry)	"night time"		Side discharge units only
				Sound suppression level	Off Quiet (1) Quieter (2) Quietest (3)	Quietest (3)		Side discharge units only
				Capacity priority	(check box)	disabled		Side discharge units only
5. Preferences			daytime (event 2 name)	time	(time selection in 15 min increments)	7am		Side discharge units only
				label	(text entry)	"day time"		Side discharge units only
				Sound suppression level	Off Quiet (1) Quieter (2) Quietest (3)	Off		Side discharge units only
				Capacity priority	(check box)	disabled		Side discharge units only
			(event 3 name)	time	(time selection in 15 min increments)	0		Side discharge units only
				label	(text entry)	NULL		Side discharge units only
				Sound suppression level	Off Quiet (1) Quieter (2) Quietest (3)	Level 1		Side discharge units only
				Capacity priority	(check box)	disabled		Side discharge units only
			(event 4 name)	(similar to event 3)		(none)		Side discharge units only
			Allow homeowner changes	(check box)		checked		Side discharge units only
		house size	500 to 10,000 sf in 100 sqft steps			not available		
	dealer information	name	(text entry)					
		phone	(text entry)					
		email	(text entry)					
		website	(text entry)					
	reminders	media filter	off, 1, 2, 3, 4, 6, or 12 months			off		if media filter
		HEPA filter	off, 1, 2, 3, 4, 6, or 12 months			off		if HEPA filter
		Electronic filter	off, 1, 2, 3, 4, 6, or 12 months			off		if Electronic filter
		UV bulbs	off, 6, 12, 18, or 24 months			off		if UV bulbs
		dehumidification filter	off, 1, 3, 6, or 12 months			off		if dehumidifier
		humidifier pad	off, 3, 6, or 12 months			off		if humidifier
		service reminder	off, 1, 2, 3, 4, 6, or 12 months			off		if service reminder setup